
### **Video Intercom Indoor Station**

## **Quick Start Guide**



#### About This Manual

All pictures, images, icons and snapshots in this manual are for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail. The manual will be updated according to the product improvement and are subject to change without prior written notice.

<u>Legal Disclaimer</u>

To the maximum extent permitted by applicable law, the product described, with its hardware, software, software and firmware, is provided "as is", with all faults and errors, and our company makes no warranties, express or implied, including particular purpose, and non-infringement of third party. In no event will our company, offices, or agents be liable to you for any special, consequential, incidental, or indirect damages, including, among others, damages for loss of business profits, business interruption, or loss of data or documentation, in connection with the use of this product, even if our company has been advised of the possibility of such damages.

With regard to the product with internet access, the use of product shall be wholly at your own risks. Our company shall be irresponsible for abnormal operation, privacy leakage or other damages resulting from cyber attack, hacker attack, virus inspection, or other internet security risks; however, our company will provide timely technical support if necessary.

During the use of the device, pleas strictly abide by applicable law. In the event of any conflicts between this manual and the applicable law, the later prevails.

#### Installation and Use

 $Please\ use\ our\ product\ according\ to\ the\ following\ safety\ instructions\ and\ warnings.$ 

Do not place the camera in extremely hot, cold, dusty or damp location.

Do not expose it to high electromagnetic radiation.

If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the camera yourself. (We shall not be responsible for any problems caused by unauthorized repair or maintenance.)

Do not drop the camera or subject it to physical shock.


Keep away from liquid while in use.


Do not touch the screen with sharp objects.

After the installation of the device is complete, please remove the protective film.

If cleaning is necessary, please use clean cloth to wipe it gently, avoiding water or alcohol.

#### 1 Package






Overview

### 3 Cable Connection

2× 10-pin Interface

	Alarin input								GND	
_										
	1	2	3	4	5	6	7	8	9	10
Γ	A1	A2	A3	A4	A5	A6	A7	A8	GND	GND
	11	12	13	14	15	16	17	18	19	20
Γ	12V IN	12V IN	GND	GND	12V OUT	GND			RS 485+	RS 485-
	+ -				+	-				
	Power Input				Power Output*				RS 485	

Alarm Innut




Note

The power output will not take effect when PoE power supply is used.

<sup>\*</sup>Only when 12VDC power supply is used to power the indoor station, can the power output be available.

### Wall Mounting without Junction Box



# $Wall\ Mounting\ with\ Junction\ Box$

